

Echoflex Installation Guide


Tri-Zone Dimming Controller

Overview

The ELED3 Tri-Zone Dimming Controller is a wireless controller with three channels to control lights in larger spaces based on room occupancy state, manual switch operation, ambient light level and gateway commands.

This document covers installation of ELED3 Tri-Zone Dimming Controller models. The *Echoflex Tri-Zone Dimming Controller ELED3 Configuration Guide* is available for download at echoflexsolutions.com.

The package contents includes the controller and the installation guide.



Prepare for Installation

Echoflex recommends paying special attention to the installation environment.

- High density construction materials and large metal appliances or fixtures in the space may disrupt wireless reception.
- Mount the controller to an electrical junction box or a panel in a location and at a height where it is not subject to tampering by unauthorized personnel.

Supplies required to install the controller (not provided):

- Appropriately sized wire nuts
- Wire insulation
- Small cable ties



Corporate Headquarters Middleton, WI, USA | **Phone** +1 608 831 4116

Web echoflexsolutions.com | **Email** info@echoflexsolutions.com | **Support** support.etcconnect.com

© 2021 Echoflex Solutions, Inc. Trademark and patent info: echoflexsolutions.com/ip

Echoflex intends this document to be provided in its entirety. Product information and specifications subject to change.

8189M2110 Rev A Released 2021-03

Echoflex Installation Guide

Tri-Zone Dimming Controller

IMPORTANT SAFEGUARDS

READ AND FOLLOW ALL SAFETY INSTRUCTIONS



WARNING: Risk of electric shock! This device utilizes high voltage and should only be installed by a qualified installer or electrician. Follow all local codes for installation. Before terminating the AC power wiring verify that the main breaker is in the off position and follow the proper lockout/tag out procedures per NFPA Standard 70E.

AVERTISSEMENT: Risque de décharge électrique! Cette appareil utilise une haute tension et ne doit être installé que par un installateur qualifié ou un électricien. Suivez tous les codes locaux pour l'installation. Avant de raccorder le câblage du courant alternatif, vérifiez que le disjoncteur principal est en position d'arrêt et suivez les procédures de Consignation/ Déconsignation prescrites par la norme NFPA 70E.



WARNING: For indoor use only! Must install to an electrical junction box or wireway.

AVERTISSEMENT: Uniquement pour usage d'intérieur! Doit être installé sur une boîte de raccordement électrique ou un chemin de câbles.

- This product is suitable for use in dry locations where the ambient temperatures is -5°C to 50°C (23°F to 122°F).
- Do not use outdoors.
- Do not mount near gas or electric heaters.
- Equipment should be mounted in locations and at heights where it is not subject to tampering by unauthorized personnel.
- The use of accessory equipment not recommended by the manufacturer may cause an unsafe condition.
- Do not use this equipment for other than its intended use.
- Servicing should be performed by qualified service personnel.
- Pollution Degree: 2.

SAVE THESE INSTRUCTIONS

Echoflex Installation Guide

Tri-Zone Dimming Controller

Installation

All local codes and standard electrical practices should be observed. Ensure that the junction box is clean and free of obstructions and that all wiring is installed correctly.



Note: *Follow applicable NEC and local electrical code requirements when installing and powering the controller.*

Install the Controller

Mount the controller directly to the exterior of the junction box or panel either at the electrical load or before the load in the circuit.

Review these instructions completely before installing the controller.

1. Locate the circuit breaker panel and terminate power to the circuit.
2. Remove the cover plate and other hardware from the junction box to access the wiring.
3. Mount the controller.
4. Refer to the wiring diagram to connect the controller to line power, neutral, and load wires. Use wire nuts on all connections and individually cap any bare wires, except the orange antenna wire.
5. Connect the gray and the striped violet wires to the driver or ballast's dimming interface.
 - Channel 1: violet/red stripe (daylighting with setpoint)
 - Channel 2: violet/blue stripe (daylighting with offset from setpoint)
 - Channel 3: violet/green stripe (non-daylighting)
6. Replace the electrical box cover plate.
7. Restore power to the circuit.




Note: *The Micro USB port is for factory use only. Do not attach cables or accessories to this port.*

Echoflex Installation Guide


Tri-Zone Dimming Controller

Wiring Diagram



Wiring Diagrams for Emergency Fixtures


Diagram 1 of 2



Echoflex Installation Guide

Tri-Zone Dimming Controller

Diagram 2 of 2



Electrical Terminations

Power to the controller is connected between the White (Neutral) and the Black Line power: ELED3 (120–277 VAC) or ELED3H (240–347 VAC). The Class 1 power limited dimming lines (gray and striped violet wires) are used to provide 0–10 V intensity control of a dimming ballast or LED driver. The orange wire is an antenna. Do not cut, cap or connect this wire. Use only UL approved wire when making connections to the controller (see table below).

Connection	Wire Color	Specification
Load	Red	14 AWG, 600 V
Neutral	White	14 AWG, 600 V
Line	Black	14 AWG, 600 V
Dimming 0-10 V	Striped Violet	18 AWG, 600 V
Dimming GND	Gray	18 AWG, 600 V

Echoflex Installation Guide

Tri-Zone Dimming Controller

Controller Interface

The controller interface has two tricolor LEDs and two buttons.

Tricolor LEDs

The Power and Learn LEDs can display red, green, or blue. LED color and combinations indicate which of the three channels is providing information via blink codes or is in an operational mode. See [Blink Codes and Operations](#) on [page 7](#).

Each of the channels can support occupancy sensors, switches or gateway commands. A photo sensor can be linked to Channel 1 for daylighting with setpoint, or to Channel 2 for daylighting with offset from setpoint.

- Red - Channel 1 - primary daylight with setpoint.
- Green - Channel 2 - secondary daylighting with offset from setpoint.
- Blue - Channel 3 - occupancy sensors, switches or gateway commands. No photo sensor (non-daylighting).

Learn Button

The **[Learn]** button initiates Link mode for linking switches or sensors in each of the controller's channels. See the relevant switch or sensor documentation for information on linking. Link mode times out after 30 seconds of inactivity.

Repeating the linking process for a device that is already linked to a controller will unlink it from that controller.

Clear Button

The **[Clear]** button resets the controller either to its pre-commissioned state or to its factory default state.

To reset to pre-commissioned state:

1. Press the **[Clear]** button until the Power and Learn LEDs start blinking.
2. Release the **[Clear]** button. The LEDs repeat a blink code by color to indicate the type and number of devices linked to each channel at pre-commissioning.

To reset to factory default state:

1. Press and hold the **[Clear]** button until the Power and Learn LEDs start blinking. Continue to hold for 15 seconds until the LEDs turn solid.
2. Release the **[Clear]** button. The Power LED displays solid red to indicate factory default state. All links are removed.

Echoflex Installation Guide

Tri-Zone Dimming Controller

Test the Controller

Echoflex provides the controller in either a pre-commissioned state or a factory default state.

- Pre-commissioned devices are linked, configured, and labelled according to customer specifications. When powered up, the LEDs repeat a blink code by color to indicate the type and number of devices currently linked to each channel. See [Blink Codes and Operations](#) on [page 7](#). To test the relay(s), press the **[Learn]** button or use a linked switch.
- In factory default state, when powered up, the Power LED displays solid red to indicate the controller has no linked devices. To test the relay(s), press the **[Learn]** button or link a switch. See relevant switch documentation.

A maximum of 20 switches or sensors can be linked to one controller.

Blink Codes and Operations

The tables below describe the controller's blink codes and operating activity for each channel by LED color. Long blinks=type. Short blinks=count.

Red is for Channel 1, Green is for Channel 2, and Blue is for Channel 3.

Blink Codes

Description	Power LED	Learn LED
Factory default (links only)	On solid (red)	Off
Switch(es)	1 long blink followed by short blinks counting switches	Off
Occupancy sensor(s)*	2 long blinks followed by short blinks counting sensors	Off
Photo sensor** (max 1)	3 long blinks followed by 1 short blink counting sensor (displays in Ch1 and Ch2)	Off
Central command	4 long blinks followed by short blinks counting devices	Off
Demand response	5 long blinks followed by short blinks counting devices	Off

*An occupancy sensor linked to any channel will appear to be linked to all three channels.

**A photo sensor linked to Ch1 or CH2 will appear to be linked to both channels.

Echoflex Installation Guide

Tri-Zone Dimming Controller

Operations

Activity	Power LED	Learn LED	Relay/Light
Link mode	Blink	On solid	Toggle
Store link ID	On 4 seconds	On solid	On 4 seconds
Clear link ID	Off 4 seconds	On solid	Off 4 seconds
Factory default	On solid	One blink (on power-up)	On solid

Compliance and Listings

For complete regulatory compliance information, see the Echoflex Tri-Zone Dimming Controller datasheet at echoflexsolutions.com.

FCC Part 15.231 Contains FCC ID: SZV-STM300U
This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1.) this device may not cause harmful interference and (2.) this device must accept any interference received, including interference that may cause undesired operation.



IC RSS-210