

ETC Quick Guide

EchoAccess Configuring Device Actions

Overview

When used in conjunction with the EchoAccess Interface or Echo Expansion Bridge, the EchoAccess App enables you to configure your Echo controls system from a mobile device or ETC Concert.



For best performance and the most recent set of features, use EchoAccess App v3.3.0 with EchoAccess Interface v3.0 or higher and/or Echo Expansion Bridge v3.0 or higher. The features discussed in this help system are available with the latest versions of Echo control system components. The configuration pages displayed by EchoAccess App for previous versions of components may appear different than what is described in this help system.

Configure

This guide provides an overview of the actions that can be assigned to individual Echo devices. For more information on configuring Echo devices, please reference the help in the EchoAccess App or the online help at etconnect.com/WebDocs/Controls/EchoAccessApp3.3.0/Welcome.htm.



ETC Quick Guide

EchoAccess Configuring Devices

Actions Per Device

	Inspire Stations				Keyswitch Stations	SmartSpace Controller and SmartSpace Controller - Gen2				Preset Stations			Light Sensor	
	Push	Push and Hold	Double Tap	Fader Action		Occ	Vac	Bright	Dark	Push	Push and Hold	Double Tap	Switched Mode	Dimmed Mode
Selection Actions														
Saturation Raise/Lower				x										
Hue Raise/Lower				x										
Tint Raise/Lower				x										
Color Temp Raise/Lower				x										
Selection Raise/Lower	x	x		x						x	x			
Selection to Level	x		x	x						x		x		
Selection Toggle	x		x	x						x				
Zone Select	x									x				
Zone Actions														
Zone Raise/Lower	x	x		x						x	x			x
Dual Zone Raise/Lower														x
Zone Set to Color	x		x	x	x					x		x		
Zone Set to Color Temp	x		x	x	x					x		x		
Zone Set to Level	x		x	x	x	x	x	x	x	x	x	x	x	
Zone Toggle	x		x	x	x					x		x		
Color Zone Hue Raise/Lower				x										
Color Zone Sat. Raise/Lower				x										
Zone Color Temp Raise/Lower				x										
Zone Tint Raise/Lower				x										
Space and Preset Actions														
Preset Activate	x*		x	x	x	x (*G2)	x (*G2)	x (*G2)	x (*G2)	x*		x		x*
Preset Toggle	x*		x	x	x					x*		x		
Record											x			
Sequence Activate					x									
Sequence Toggle	x				x					x				
Space Combine Toggle	x				x					x				
Space Combine/Uncombine	x				x					x				
Space Off	x*		x	x	x		x (*G2)	x (*G2)	x (*G2)	x*		x		x*
Space Raise/Lower	x	x		x						x	x			x
Space Set to Color	x		x	x	x					x		x		
Space Set to Color Temp	x		x	x	x					x		x		
Space Set to Level	x		x	x	x	x	x	x	x	x		x	x	
Space Toggle	x		x	x	x					x		x		
Special Actions														
HSI Color Mode				x										
Color Temp Mode				x										
Studio Mode				x										
Space Lockout Toggle					x									
Space Lockout Enable/Disable					x									
Timeclock Hold Toggle	x		x							x		x		
Timeclock Hold Enable/Disable	x		x							x		x		

* Multi Space option available

*G2 Multi Space option available with Gen 2 version

ETC Quick Guide

EchoAccess Configuring Devices

	Contact Input Interface						PIR Occupancy Sensors		PIR Vacancy Sensors	Dual Tech Switch-mount Occupancy Sensors (buttons)		
	Momentary			Maintained	Occupancy		Occupancy Event	Vacancy Event	Vacancy Event	Push	Push and Hold	Double Tap
	Push	Double Tap	Hold	Open/Closed	Occupancy Event	Vacancy Event						
Selection Actions												
Saturation Raise/Lower												
Hue Raise/Lower												
Tint Raise/Lower												
Color Temp Raise/Lower												
Selection Raise/Lower												
Selection to Level												
Selection Toggle												
Zone Select												
Zone Actions												
Zone Raise/Lower	x		x							x	x	
Dual Zone Raise/Lower												
Zone Set to Color	x	x		x						x		x
Zone Set to Color Temp	x	x		x						x		x
Zone Set to Level	x	x		x	x	x	x	x	x	x		x
Zone Toggle	x	x								x		x
Color Zone Hue Raise/Lower												
Color Zone Sat. Raise/Lower												
Zone Color Temp Raise/Lower												
Zone Tint Raise/Lower												
Space and Preset Actions												
Preset Activate	x*	x		x*	x*	x*	x*	x*	x*	x*		x
Preset Toggle	x*	x								x*		x
Record												
Sequence Activate	x			x								
Sequence Toggle	x									x		
Space Combine Toggle	x									x		
Space Combine/Uncombine	x			x						x		
Space Off	x*	x		x*		x*		x*	x*	x*		x
Space Raise/Lower	x		x							x	x	
Space Set to Color	x	x		x						x		x
Space Set to Color Temp	x	x		x						x		x
Space Set to Level	x	x		x	x	x	x	x	x	x		x
Space Toggle	x	x								x		x
Special Actions												
HSI Color Mode												
Color Temp Mode												
Studio Mode												
Space Lockout Toggle	x											
Space Lockout Enable/Disable	x			x								
Timeclock Hold Toggle	x	x								x		x
Timeclock Hold Enable/Disable	x	x		x						x		x

* Multi Space option available

ETC Quick Guide

EchoAccess Configuring Devices

	Room Controller AV Input		Room Controller - Gen2 Sensor Input					
	Momentary	Maintained	Momentary			Maintained	Occupancy	
	Contact Close	Contact Open/Close	Push	Double Tap	Hold	Open/Closed	Occupancy Event	Vacancy Event
Selection Actions								
Saturation Raise/Lower								
Hue Raise/Lower								
Tint Raise/Lower								
Color Temp Raise/Lower								
Selection Raise/Lower								
Selection to Level								
Selection Toggle								
Zone Select								
Zone Actions								
Zone Raise/Lower			x		x			
Dual Zone Raise/Lower								
Zone Set to Color			x	x		x		
Zone Set to Color Temp			x	x		x		
Zone Set to Level			x	x		x	x	x
Zone Toggle			x	x				
Color Zone Hue Raise/Lower								
Color Zone Sat. Raise/Lower								
Zone Color Temp Raise/Lower								
Zone Tint Raise/Lower								
Space and Preset Actions								
Preset Activate	x	x	x*	x		x*	x*	x*
Preset Toggle	x		x*	x				
Record								
Sequence Activate			x			x		
Sequence Toggle			x					
Space Combine Toggle			x					
Space Combine/Uncombine			x			x		
Space Off	x	x	x*	x		x*		x*
Space Raise/Lower			x		x			
Space Set to Color	x	x	x	x		x		
Space Set to Color Temp			x	x		x		
Space Set to Level	x	x	x	x		x	x	x
Space Toggle	x		x	x				
Special Actions								
HSI Color Mode								
Color Temp Mode								
Studio Mode								
Space Lockout Toggle			x					
Space Lockout Enable/Disable			x			x		
Timeclock Hold Toggle			x	x				
Timeclock Hold Enable/Disable			x	x		x		

* Multi Space option available