



Typical Wiring Diagram - ELAHO SMART SPACE CONTROLLER (ESSC)
Set as Occupancy Transmitter for Time-Clock override of local occupancy control

Echoflex Solutions, Inc.

38924 Queens Way Unit #1
Squamish, British Columbia
Canada V8B 0K8
Phone: 1 (778) 733-0111
Toll Free: 1 (888) 324-6359
Fax: 1 (604) 815-0078
echoflexsolutions.com

